Exclusions from Warranty


1.Damage or malfunction caused by unauthorized repair, misuse, collision, negligence, abuse, liquid ingress, accidents, modification, improper operation, tampering, or removal of labels.

2.Products beyond the warranty period.

3.Damage caused by force majeure.

4.Performance faults resulting from human factors.

Please read this manual carefully
before using the product.



G–10S

Issue	Possible Cause	Solution
Cracks or damage on the microphone housing	Structural stress or material defects	Stop using immediately and contact customer service for repair or replacement.
Power switch stuck or unable to turn on/off	Mechanical jam or internal component fault	Gently toggle the switch a few times. If the issue remains, contact service.
Abnormalities in the PA system, unable to operate normally	Fault in connected audio equipment or improper connections	Check all cables and connections. Restart the system. If unresolved, seek technical support.

Product Introduction

Thank you for choosing this product. This is a professional vocal microphone featuring a dynamic capsule design with a supercardioid pickup pattern. It effectively reduces feedback and ensures clear, high–quality sound reproduction. The built–in windscreen and pop filter provide reliable noise suppression and stable performance, making it suitable for various professional recording and live performance applications.

Specifications

Model: Musiccube G–10S

Dimensions: ø51±1.5mm* 170±2mm

Weight：210g±10g

Transducer Type: Dynamic

Polar Pattern: Supercardioid

Frequency Response: 60 Hz — 16 kHz

Impedance: 600 Ω ±15%

Sensitivity：–51dB±3dB（at 1KHz）



Manufacturer: Shenzhen LiPing Technology Co.,Ltd.
Website: www.musiccube.com.cn
E-Maill:massfun@musiccube.com.cn
Address: 9F,Building 2,Baolong Specialized and Sophisticated Industrial Park,Longgang District,Shenzhen,China

● Connection Instructions

- Insert the microphone into the XLR connector and tighten the plug to secure the connection.
- When disconnecting the microphone, please turn the connector counterclockwise and gently remove the cable from the microphone.

● Usage Instructions

- Ensure the microphone is connected to a suitable sound input device to avoid noise or signal distortion.
- After using the microphone, verify that the microphone is properly stored to prevent unwanted feedback or damage.
- Avoid placing the microphone near equipment that may emit electromagnetic interference, to minimize the risk of unwanted noise in the audio.

● Important Notes

- When the microphone is used with a sound system or close to amplifiers, it may pick up noise. If this occurs, adjust the audio equipment's volume to a lower level and move the microphone further from the amplifier.
- Regularly clean the microphone and plug to ensure clear sound and avoid distortion or feedback.
- Do not use the microphone near high–temperature or noisy environments, as this may affect the microphone's sensitivity and performance.

musiccube

G-10S

Dynamic Vocal Microphone

User Manual

Warranty Statement

Warranty Terms

Our company provides after-sales service according to the "Consumer Protection Law of the People's Republic of China" and the "Product Quality Law of the People's Republic of China." The after-sales service is as follows:

1、If the product shows performance faults listed under "Product Performance Faults" within 7 days after the customer signs for receipt, our after-sales service department will verify the issue, and the customer is entitled to free return or exchange services.

2、If the product shows performance faults within 8-15 days after the customer signs for receipt, our after-sales service department will verify the issue, and the customer is entitled to free exchange or repair services.

3、If the product shows performance faults within 12 months after the customer signs for receipt, our after-sales service department will verify the issue, and the customer is entitled to free maintenance services.